

## FeatherBrite

E-mail : sales@featherbrite.com

### INSTALLATION INSTRUCTIONS

**BULBS** - Screw bulbs into the appropriate sockets by the ballast, not the actual bulb. The UV bulb fits into the candelabra socket and the daylight bulb fits into the standard socket. Mount the shade to the wire attachments using the 4 (four) flat washers and wing nuts. Bulb replacements are available on our website. Replace daylight bulb annually. Replace UV bulb every 8 months for maximum results.

**UNIVERSAL LIGHTS** are designed to fit most cage tops. The wire cage attachment is designed to fit securely between the cage bars. The wires can be pushed or pulled slightly to fit in the cage bars. Press down on wire attachment firmly to attach to top of cage. Do not attach to the side of cages.

The wire attachments can be mounted to fit cages that have horizontal wires, vertical wires and they can be turned inward to fit the smaller dome tops. The loops can be used to hang toys, swings or other accessories your bird enjoys!

**SWAG LIGHTS** – To maximize the benefits of the full spectrum bulb, hang light as close to the cage as possible (recommended 12"-24"). Make certain the light is a safe distance from your pet to avoid contact with bulb, shade and electrical cord.

**This is an electrical appliance.** Make certain that the electrical cord is hanging away from back of cage so that your bird cannot reach the electrical cord. If your pet comes out of the cage, remove and unplug the light from the cage to keep your pet away from the unit and the electrical cord.

We are not responsible for any damage incurred.

### PRODUCT RETURNS

If you are not satisfied with our product, returns must be made within 30 days of original purchase and be returned in the original packaging. When returning, items must arrive unused and undamaged. It is the responsibility of the purchaser to insure the package contents. Credit will be given when merchandise is received unused and undamaged. If merchandise is not returned in the original packaging, damage will occur to the products.

### WARRANTY CLAIMS

We must receive all warranted products and/or parts shipped prepaid by the customer. Any structural damage to components of any kind voids any and all warranties. If merchandise is not returned in the original packaging, damage will occur to the products. Our warranty covers any defects with the exception to structural damage and use of the product for any purchase other than its intended use.

### WARRANTY TERMS

FeatherBrite warrants the products to be free of defects and workmanship for a period of one year from the date of purchase.

Please return merchandise to:

FeatherBrite  
602 E. Pennsylvania Blvd.  
Feasterville, PA 19053